

Places to Check for Harmful Radiations

SUGGESTED ORDER OF IMPORTANCE

- ◆ Electrical service entry box (circuit breaker box)
- ◆ Gas or electrical hot water heater
- ◆ Ground radiations (below floor rising) where you sleep, work
- ◆ Above ground radiations, transformers, power sub-stations
- ◆ Cell phone and broadcast towers, microwave, military and airport radar, etc
- ◆ Overhead radiations from wiring, fluorescent lights, floor or sky above.
- ◆ Move all electrical outlets or appliances at least four feet from your bed, or "clear" them.
- ◆ A refrigerator on the other side of the wall may go on while you sleep.
- ◆ Clear all electronic appliances within four feet of where you work.

ELECTRICAL ENERGY SERVICE

Power lines serve as a long antenna for radio waves, static, computer communications, even telephone for those who plug their phones into outlets. They also carry too much of the wrong polarity. This causes things to grow, like cancer and infections. Notice how trees grow into power lines. Most plants prefer South Polar magnetic fields. When you clear incoming power, you still need to clear individual appliances.

EXAMPLE: My granddaughter received a small battery-powered plastic sewing machine for Christmas. Battery powered or not, it jammed the TV twelve feet away every time she operated it.

WATER HEATERS

All water heaters emit both a vertical vortex of energy, and a horizontal ray. If the water heater is in the basement below your bed, or the ray passes through a work or sleep area, it is likely that you will have health problems.

Many homes do not have an adequate eight-foot long ground rod, and the upper levels of the soil are too dry to ground well. Washers, dryers, food disposals, and neighboring houses also ground to water lines. Clear your water heater by placing a clearing device near or aimed at the cold water entry pipe. This will also clean the electrical fields carried by the pipes through walls, floors, and possibly ceilings.

GEOPATHIC ZONES

Geo means ground. Pathogenic means harmful. These zones are rarely simple anymore, because the ground has become highly electrified. Half of each electrical circuit flows through the ground, so underground water is now charged with all the stuff carried by power lines. Research has shown that office equipment, or even cars parked over such zones, may develop electrical or mechanical malfunctions. Quite often, computers and copiers continually need service when placed over such zones.

Persons working or sleeping over such zones have been shown to have changes in blood sedimentation (University of Vienna) in as little as ten minutes exposure time. People also develop hypertension, cancer, arthritis, and irritability. Exposure to these zones can result in lower productivity, higher employee turnover, and greatly increased divorce rates. After all, just like electronic appliances, people are total electric. The central nervous system operates on very low voltage, yet controls all bodily organs and functions.

ABOVE GROUND RADIATIONS

Above ground radiations are very common, and can appear at any time due to the addition of a new appliance in a neighboring apartment, a new powerline transformer nearby, a new microwave dish added on the mountain or at a business, TV and radio broadcasting towers, and certainly cell phone communication towers. Australian studies have shown that cell phone relay towers can emit ten times a safe level of X-ray when they malfunction. The radiation levels can be heavier at a distance. Check for radiations entering a building through the walls. The problems are easy to correct, but no amount of radiation of this type is desirable. It is a good practice to recheck every so often. New radiations have a way of being added, sometimes coming as a bounce when a new roof or metal object is added to the neighborhood. For Feng Shui practitioners, remember that when this practice was started 4,000 years ago in China, Emperor Kwang Yu decreed that no house could be built until first checked for The Claw of the Dragon (Geopathic Zones). So Feng Shui developed in a time when by nature, homes were already free of these energies. With the coming of the age of electronic communication and appliances, you need to develop additional remedies if you have not already done so.

OVERHEAD RADIATIONS

Overhead wiring, fluorescent lights set too close, radiations from upper floor appliances. The UN Building in New York is a prime example: Hundreds of computers on floors above and below, wiring everywhere, surveillance from within and without, microwave dishes, etc. But, many offices and even homes have these problems too.

Fluorescent lights in milk counters have been shown to destroy 30% of the Vitamin A in the milk in just 24 hours. Vitamin A strengthens the immune system. If left uncleared, what are these lights doing to those working under them for extended periods of time? The lights are also high frequency.

CLEAR ALL APPLIANCES WITHIN 3 FEET OF WHERE YOU WORK OR SLEEP

A circuit breaker (fused) outlet can produce 200 times the magnetic field of your own body within three feet distance. All outlets do radiate. If you have an outlet by the head of your bed, or an electronic clock, etc, clear them or move them at least four feet away. At the very least, these affect your sleep/rest/heal cycles.

CLEAR ALL APPLIANCES YOU SPEND A LOT OF TIME NEAR

No single solution will clear your whole building. Besides, some energies are quite beneficial. Clear the ones that are harmful. Find the good ones, and spend time there too. In nature there is always balance.

FINALLY, CLEAR YOURSELF!

For more information about hazardous energies, energy products or to schedule a phone consultation to discuss what you are experiencing, please contact Linda White at 910-232-0627. We will be happy to consult with you via phone and/or schedule a time to come in and evaluate your space and recommend the appropriate products.